



**Biketronics Inc.**

  
Innovative V-Twin Electronics

630 N Almon #140 N  
Moscow, Idaho 83843  
Tel. (208) 882-8469  
Fax (208) 882-5938  
[www.biketronics.com](http://www.biketronics.com)

## Radio Installation

- Wire cage **MUST** be removed on '96 and newer – will block mounting holes
- Radio goes in from **BACK** of fairing, not the tank side on '96 and newer
- Small black headphone cord **MUST** be plugged in for handlebar control
- Make sure blocks are on correctly, they should come up above the top of the radio by  $\frac{1}{4}$  inch. If holes do not line up, see #1 or swap sides, left and right sides are different.

## No Automatic Volume Control (AVC)

- Make sure the small black cord is plugged securely into the back of the radio, and is making full contact
- Reset AVC by holding the left switch in for 8 seconds, letting go, and then quickly pushing up on the left switch 4 times. You will not see anything happen on the radio if this process works correctly. Wait 5 seconds before touching the radio after making the changes.